

CHAPTER III

THEORY

A typical chemical plant flowsheet has a mixture of multiple units connected both in series and parallel that consist of reaction sections, separation sections and heat exchanger network. So Plantwide Process Control involves the system and strategies required to control entire plant consisting of many interconnected unit operations.

3.1 Incentives for Chemical Process Control

A chemical plant is an arrangement of processing units (reactors, heat exchangers, pumps, distillation columns, absorbers, evaporators, tanks, etc.), integrated with one another in a systematic and rational manner. The plant's overall objective is to convert certain raw materials into desired products using available source of energy, in the most economical way.

There are three general classes of needs that a control system is called on to satisfy: suppressing the influence of external disturbances, ensuring the stability of a chemical process, and optimizing the performance of a chemical process.

3.1.1 Suppressing the Influence of External Disturbances

Suppressing the influence of external disturbances on a process is the most common objective of a controller in a chemical plant. Such disturbances, which denote the effect that the surroundings have on the reactor, separator, heat exchanger, and compressor, are usually out of the reach of human operator. Consequently, we need to introduce a control mechanism that will make the proper change on the process to cancel the negative impact that such disturbances may have on the desired operation of a chemical plant.

3.1.2 Ensuring the Stability of a Chemical Process

The process is stable or self-regulating, if the process variables such as temperature, pressure, concentration, or flowrate stay at a certain point or a desired steady state value as time progresses. Otherwise, the process is unstable and requires external control for the stabilization of their behavior.

3.1.3 Optimizing the Performance of a Chemical Process

Safety and the satisfaction of product specifications are the two principal operational objectives for a chemical plant. Once these are achieved, the next goal is how to make the operation of the plant more profitable. Given the fact that the conditions that affect the operation of the plant do not remain the same, it is clear that we would like to be able to change the operation of the plant (flowrate, pressure, concentration, temperature) in such a way that an economic objective is always maximized.

3.2 Integrated Process

Three basic features of integrated chemical process lie at the root of our need to consider the entire plant's control system: the effect of material recycle, the effect of energy integration, and the need to account for chemical component inventories.

3.2.1 Material Recycles

Material is recycled for six basic and important reasons.

1. Increase conversion.

For chemical processes involving reversible reactions, conversion of reactants to products is limited by thermodynamic equilibrium constraints. Therefore the reactor effluent by necessity contains both reactants and products. Separation and recycle of reactants are essential if the process is to be economically viable.

2. Improve economics.

In most systems it is simply cheaper to build a reactor with incomplete conversion and recycle reactants than it is to reach the necessary conversion level in one reactor or several in series. A reactor followed by a stripping column with recycle is cheaper than one large reactor or three reactors in series.

3. Improve yields.

In reaction system such as $A \rightarrow B \rightarrow C$, where B is the desired product, the per-pass conversion of A must be kept low to avoid producing too much of the undesirable product C. Therefore the concentration of B is kept fairly low in the reactor and a large recycle of A is required.

4. Provide thermal sink

In adiabatic reactors and in reactors where cooling is difficult and exothermic heat effects are large, it is often necessary to feed excess material to the reactor (an excess of one reactant or a product) so that the reactor temperature increase will not be too large. High temperature can potentially create several unpleasant events: it can lead to thermal runaways, it can deactivate catalysts, it can cause undesirable side reactions, it can cause mechanical failure of equipment, etc. So the heat of reaction is absorbed by the sensible heat required to rise the temperature of the excess material in the stream flowing through the reactor.

5. Prevent side reactions.

A large excess of one of the reactants is often used so that the concentration of the other reactant is kept low. If this limiting reactant is not kept in low concentration, it could react to produce undesirable products. Therefore the reactant that is in excess must be separated from the product components in the reactor effluent stream and recycled back to the reactor.

6. Control properties.

In many polymerization reactors, conversion of monomer is limited to achieve the desired polymer properties. These include average molecular weight, molecular weight distribution, degree of branching, particle size, etc. Another reason for limiting conversion to polymer is to control the increase in viscosity that is typical of polymer solutions. This facilitates reactor agitation and heat removal and allows the material to be further processed.

3.2.2 Energy Integration

The fundamental reason for the use of energy integration is to improve the thermodynamics efficiency of the process. This translates into a reduction in utility cost.

3.2.3 Chemical Component Inventories

In chemical processes can characterize a plant's chemical species into three types: reactants, products, and inert. The real problem usually arises when we consider reactants (because of recycle) and account for their inventories within the entire process. Every molecule of reactants fed into the plant must either be consumed or leave as impurity or purge. Because of their value so we prevent reactants from leaving. This means we must ensure that every mole of reactant fed to the process is consumed by the reactions.

This is an important, from the viewpoint of individual unit, chemical component balancing is not a problem because exit streams from the unit automatically adjust their flows and composition. However, when we connect units together with recycle streams, the entire system behaves almost like a pure integrator in terms of reactants. If additional reactant is fed into the system without changing reactor conditions to consume the reactants, this component will build up gradually within the plant because it has no place to leave the system.

3.3 Effects of Recycle

Most real processes contain recycle streams. In this case the plantwide control problem becomes much more complex. Two basic effect of recycle is: Recycle has an impact on the dynamics of the process. The overall time constant can be much different than the sum of the time constants of the time constants of the individual units. Recycle leads to the "snowball" effect. A small change in throughput or feed composition can lead to a large change in steady-state recycle stream flowrates.

3.3.1 Snowball Effect

Snowball effect is high sensitivity of the recycle flowrates to small disturbances. When feed conditions are not very different, recycle flowrates increase drastically, usually over a considerable period of time. Often the equipment cannot handle such a large load. It is a steady-state phenomenon but it does have dynamic implications for disturbance propagation and for inventory control.

The large swings in recycle flowrates are undesirable in plant because they can overload the capacity of separation section or move the separation section into a flow region below its minimum turndown. Therefore it is important to select a plantwide control structure that avoids this effect.

3.4 Basic Concepts of Plantwide Control

3.4.1 Buckley Basic

Page Buckley (1964) was the first to suggest the idea of separating the plantwide control problem into two parts:

1. Material balance control.
2. Production quality control.

He suggested looking first at the flow of material through the system. A logical arrangement of level and pressure control loop is established, using the flowrates of liquid and gas process streams. He then proposed establishing the product-quality control loops by choosing appropriate manipulated variables. The time constants of the closed-loop product-quality loops are estimated as small as possible. The most level controllers should be proportional-only (P) to achieve flow smoothing.

3.4.2 Douglas Doctrines

Jim Douglas (1988) has devised a hierarchical approach to the conceptual design of process flowsheets. Douglas points out that in the typical chemical plant the costs of raw materials and the value of the products are usually much greater than the costs of capital and energy. This leads to two Douglas doctrines.

1. Minimize losses of reactants and products.
2. Maximize flowrates through gas recycle systems.

The first implies that we need tight control of stream composition exiting the process to avoid losses of reactants and products. The second rests on the principle that yield is worth more than energy.

The control structure implication is that we do not attempt to regulate the gas recycle flow and we do not worry about what we control with its manipulation. We simply maximize its flow. This removes one control degree of freedom and simplifies the control problem.

3.4.3 Downs Drill

Jim Downs (1992) pointed out the importance of looking at the chemical component balances around the entire plant and checking to see that the control structure handles these component balances effectively. We must ensure that all components (reactants, product, and inert) have a way to leave or be consumed within the process. Most of the problems occur in the consideration of reactants, particularly when several chemical species are involved. Because we usually want to minimize raw material costs and maintain high-purity products, most of the reactants fed into the process must be chewed up in the reactions. And the stoichiometry must be satisfied down to the last molecule. Chemical plants often act as pure integrators in terms of reactants will result in the process gradually filling up with the reactant component that is in excess. There must be a way to adjust the fresh feed flowrates so that exactly the right amounts of the two reactants are fed in.

3.4.4 Luyben Laws

Three laws have been developed as a result of a number of case studies of many types of system:

- (1) All recycle loops should be flow controlled.
- (2) A fresh reactant feed stream cannot be flow-controlled unless there is essentially complete one-pass conversion of one of the reactants.
- (3) If the final product from a process comes out the top of a distillation column, the column feed should be liquid. If the final product comes out the bottom of a column, the feed to the column should be vapor (Cantrell et al., 1995). Even if steady-state economics favor a liquid feed stream, the profitability of an operating plant with a product leaving the bottom of a column may be much better if the feed to column is vaporized.

3.4.5 Richardson Rule

Bob Richardson suggested the heuristic that the largest stream should be selected to control the liquid level in a vessel. (The bigger the handle you have to affect a process, the better you can control it).

3.4.6 Shinskey Schemes

Greg Shinskey (1988) has produced a number of “advanced control” structures that permit improvements in dynamic performance.

3.4.7 Tyreus Tuning

Use of P-only controllers for liquid levels, turning of P controller is usually trivial: set the controller gain equal to 1.67. This will have the valve wide open when the level is at 80 percent and the valve shut when the level is at 20 percent.

For other control loops, suggest the use of PI controllers. The relay-feedback test is a simple and fast way to obtain the ultimate gain (K_u) and ultimate period (P_u).

Then either the Ziegler-Nichols setting or the Tyreus-Luyben (1992) settings can be used:

$$K_{ZN} = K_u/2.2 \qquad \tau_{ZN} = P_u/1.2$$

$$K_{TL} = K_u/3.2 \qquad \tau_{TL} = 2.2P_u$$

The use of PID controllers, the controlled variable should have a very large signal-to-noise ratio and tight dynamic control is really essential from a feedback control stability perspective.

3.5 Step of Plantwide Process Control Design Procedure

Step1: Establish control objectives

Assess the steady-state design and dynamic control objects for the process. This is probably the most important aspect of the problem because different control objectives lead to different control structures. The “best” control structure for a plant depends upon the design and control criteria established.

These objectives include reactor and separation yields, product quality specification, product grades and demand determination, environmental restrictions, and the range of safe operating conditions.

Step 2: Determine control degrees of freedom

This is the number of degrees of freedom for control, i.e., the number of variables that can be controlled to set point. The placement of these control valves can sometimes be made to improve dynamic performance, but often there is no choice in their location.

Most of these valves will be used to achieve basic regulatory control of the process: set production rate, maintain gas and liquid inventories, control product

qualities, and avoid safety and environmental constraints. Any valves that remain after these vital tasks have been accomplished can be utilized to enhance steady-state economic objectives or dynamic controllability (e.g. minimizes energy consumption, maximize yield, or reject disturbances).

Step 3: Establish energy management system

Make sure that energy disturbances do not propagate throughout the process by transferring the variability to the plant utility system.

We use the term energy management to describe two functions.

1. We must provide a control system that removes exothermic heats of reaction from the process. If heat is not removed to utilities directly at the reactor, then it can be used elsewhere in the process by other unit operations. This heat, however, must ultimately be dissipated to utilities.
2. If heat integration does occur between process streams, then the second function of energy management is to provide a control system that prevents the propagation of thermal disturbances and ensure the exothermic reactor heat is dissipated and not recycled. Process-to-process heat exchangers and heat-integrated unit operations must be analyzed to determine that there are sufficient degrees of freedom for control.

Heat removal in exothermic reactors is crucial because of the potential for thermal runaways. In endothermic reactions, failure to add enough heat simply results in the reaction slowing up. If the exothermic reactor is running adiabatically, the control system must prevent excessive temperature rise through the reactor.

Heat integration of a distillation column with other columns or with reactors is widely used in chemical plants to reduce energy consumption. While these designs look great in terms of steady-state economics, they can lead to complex dynamic behavior and poor performance due to recycling of disturbances. If not already included in the design, trim heater/cooler or heat exchanger bypass line must be added to prevent this. Energy disturbances should be transferred to the plant utility system whenever possible to remove this source of variability from the process units.

Step 4: Set production rate

Establish the variable that dominates the productivity of the reactor and determine the most appropriate manipulator to control production rate. To obtain higher production rate, we must increase overall reaction rates. This can be accomplished by raising temperature, increasing reactant concentrations, increasing reactor holdup, or increasing reactor pressure. The variable we select must be dominant for the reactor

We often want to select a variable that has the least effect on the separation section but also has a rapid and direct effect on reaction rate in the reactor without hitting an operational constraint.

Step 5: Control product quality and handle safety, operational, and environmental constraints

We should select manipulated variables such that the dynamic relationships between the controlled and manipulated variables feature small time constants and dead times and large steady-state gains.

It should be noted that, since product quality considerations have become more important, so it should be established the product-quality loops first, before the material balance control structure.

Step 6: Fix a flow in every recycle loop and control inventories (pressure and level)

In most processes a flow controller should be present in all liquid recycle loops. This is a simple and effective way to prevent potentially large changes in recycle flows that can occur if all flows in the recycle loop are controlled by level. We have to determine what valve should be used to control each inventory variable. Inventories include all liquid levels (except for surge volume in certain liquid recycle streams) and gas pressures. An inventory variable should be controlled with the manipulated variable that has the largest effect on it within that unit (Richardson rule).

Gas recycle loops are normally set at maximum circulation rate, as limited by compressor capacity, to achieve maximum yields (Douglas doctrine)

Proportional-only control should be used in non-reactive level loops for cascade units in series. Even in reactor level control, proportional control should be considered to help filter flowrate disturbances to the downstream separation system.

Step 7: Check component balances

Component balances are particularly important in process with recycle streams because of their integrating effect. We must identify the specific mechanism or control loop to guarantee that there will be no uncontrollable buildup of any chemical component within the process (Downs drill).

In process, we don't want reactant components to leave in the product streams because of the yield loss and the desired product purity specification. Hence we are limited to the use of two methods: consuming the reactants by reaction or adjusting their fresh feed flow. The purge rate is adjusted to control the inert composition in the recycle stream so that an economic balance is maintained between capital and operating costs.

Step 8: Control individual unit operations

Establish the control loops necessary to operate each of the individual unit operations. A tubular reactor usually requires control of inlet temperature. High-temperature endothermic reactions typically have a control system to adjust the fuel flowrate to a furnace supplying energy to the reactor.

Step 9: Optimize economics or improve dynamic controllability

After satisfying all of the basic regulatory requirements, we usually have additional degrees of freedom involving control valves that have not been used and setpoints in some controllers that can be adjusted. These can be used either to

optimize steady-state economic process performance (e.g. minimize energy, maximize selectivity) or improve dynamic response.

3.6 Plantwide Energy Management

3.6.1 Heat Exchanger Dynamics

Heat exchangers have fast dynamics compared to other unit operations in a process. Normally the time constant is measured in second but could be up to a few minutes for large exchangers. Process-to-process exchangers should be modeled rigorously by partial differential equations since they are distributed systems. This introduces the correct amount of dead time and time constant in exit stream temperatures, but the models are inconvenient to solve.

For propose of plantwide control studies it is not necessary to have such detailed descriptions of the exchanger dynamics, since these units rarely dominate the process response. Instead, it is often possible to construct useful models by letting two sets of well-stirred tanks in series heat exchanger.

3.6.2 Heat Pathways

The most of energy required for heating certain streams within the process is matched by similar amount required for cooling other streams. Heat recover from cooling a stream could be recycled back into the process and used to heat another stream. This is the purpose of heat integration and heat exchanger networks (HENs).

From a plantwide perspective we can now discern three different “heat pathways” in the process. See Figure 3.1 for an illustration. The first pathway dissipates to the environment heat generated by exothermic reaction and by degradation of mechanical work (e.g. compression, pressure drop, and friction). This pathway is from inside the process and flow out. It is of course possible to convert some of the heat to work as it is removed from high temperature in the process.




Figure 3.1: Heat pathways.

A second pathway carries heat from utilities into the process. Mechanical work is extracted from the heat as it flows from a high supply way goes through the process and is needed to satisfy the thermodynamic work requirements of separation. Work is also extracted from the heat stream to overcome process inefficiencies with stream mixing and heat transfer.

The third pathway is internal to process. Here heat flows back and forth between different unit operations. The magnitude of this energy path depends upon the heating and cooling needs and the amount of heat integration implemented. Whenever the internal path is missing, and there is a heating requirement, the heat has to be supplied from utilities. The same amount of heat must eventually be rejected to the environment elsewhere in the process.

3.6.3 Heat Recovery

We can make great improvements in the plant's thermal efficiency by recycling much of the energy needed for heating and cooling process streams. There is of course a capital expense associated with improved efficiency but it can usually be justified when the energy savings are accounted for during the lifetime of the project. Of more interest to us in the current context is how heat integration affects the dynamics and control of a plant and how we can manage energy in plants with a high degree of heat recovery.

3.6.4 Control of Utility Exchangers

The purpose of unit operation controls is to regulate the amount of energy supplied or removed. This is typically done by measuring a temperature in the process and manipulating the flowrate of utility. A PI-controller is adequate in most instances. The location of the temperature measurement depends upon the purpose of the heat exchange. The control point should be located where the effects of the added energy are felt the most. When the utility exchanger is used for stream heating and cooling, the control point is on the stream being heated or cooled.

3.6.5 Control of Process-to-Process Exchangers

Process-to-process (P/P) exchangers are used for heat recovery within a process. Most heat exchanger network are not operable at the optimum steady state design conditions; i.e., normally they can tolerate disturbances that decrease the loads but not those that increase loads and there not an adequate number of manipulative variables to be able to satisfy the process constraints and to optimize all of the significant operating variables. These types of operability limitations can be identified by using steady state considerations, and normally these operability limitations can be overcome by installing an appropriate utility exchanger and by installing bypass around the exchangers.

3.6.5.1 Use of Auxiliary Exchangers

When the P/P exchanger is combined with a utility exchanger, we also have a few design decisions to make. The utility exchanger can be installed to P/P exchanger either in series or parallel. Figure 3.2 shows the combination of P/P exchanger with a utility exchanger. Generally, the utility system of a complex energy-integrated plant is designed to absorb large disturbances in the process, and making process-to-utility exchangers relatively easy to control.

The relative sizes between the recovery and the utility exchangers must be established. From a design standpoint we would like to make the recovery exchanger

large and utility exchanger small. This gives the most heat recovery, and it is also the least expensive alternative from an investment standpoint.

3.6.5.2 Use of Bypass Control

When the bypass method is used for unit operation control, we have several choices about the bypass location and the control point. Figure 3.3 shows the most common alternatives. For choosing the best option, it depends on how we define the best. Design consideration might suggest, we measure and bypass on the cold side since it is typically less expensive to install a measurement device and a control valve for cold service than it is for high-temperature service. Cost consideration would also suggest a small bypass flow to minimize the exchanger and control valve sizes.

From a control standpoint, we should measure the most important stream, regardless of temperature, and bypass on the same side as well we control (see Figure 3.3 a and c). This minimizes the effects of exchanger dynamics in the loop. We should also want to bypass a large fraction of the controlled stream since it improves the control range. This requires a large heat exchanger. There are several general heuristic guidelines for heat exchanger bypass streams. We typically want to bypass the flow of the stream whose temperature we want to control. The bypass should be about 5 to 10 percent of the flow to be able to handle disturbances. Finally, we must carefully consider the fluid mechanics of the bypass design for the pressure drops through the control valves and heat exchanger.

3.7 Heat Exchanger Network

It is generally accepted that an optimal network must feature a minimum number of units that reflects on a capital cost and minimum utility consumption that reflects on operating costs. A good engineering design must exhibit minimum capital and operating costs. For Heat Exchanger Network (HEN) synthesis, other features that are usually considered in design are operability, reliability, safety, etc. in recent years the attention in HEN synthesis has been focused on the operability features of a HEN, e.g. the ability of a HEN to tolerate unwanted changes in operating conditions.

It has been learned that considering only a cost objective in synthesis may lead to a worse network, i.e. a minimum cost network may not be operable at some neighboring operating conditions. The design must not only feature minimum cost, but also be able cope with a fluctuation or changes in operating conditions. The ability of a HEN to tolerate unwanted changes is called *resiliency*. It should be noted that the ability of a HEN to tolerate wanted changes is called *flexibility*.




Figure 3.2: Control of process-to-process heat exchanger using the auxiliary utility




Figure 3.3: Bypass controls of process-to-process heat exchangers.

The resiliency property of a design becomes an important feature to be accounted for when the extent of integration of a design introduces significant interactions among process components. The energy integration of a HEN generates a

quite complex interaction of process streams, despite the fact that transfer of heat from hot to cold process streams is the only activity of the network. The goal of a network is to deliver the process streams to their target temperatures by using most of their heating and cooling availability and a minimum of heating and cooling utilities. The process streams are coupled through a net of heat exchangers. Changes in conditions of one stream in the network may affect the performances of many heat exchanges and the conditions of several process streams. Since resiliency is a property of a network structure.

3.7.1 Definition of HEN Resiliency

In the literature, resiliency and flexibility have been used synonymously to describe the property of HEN to satisfactorily handle variations in operating conditions. These two terms have difference in meaning.

The resiliency of a HEN is defined as the ability of a network to tolerate or remain feasible for disturbances in operating conditions (e.g. fluctuations of input temperatures, heat capacity flowrate, etc.). As mentioned before, HEN flexibility is closed in meaning to HEN resiliency, but HEN flexibility usually refers to the wanted changes of process conditions, e.g. different nominal operating conditions, different feed stocks, etc. That is, HEN flexibility refers to the preservation of satisfactory performance despite varying conditions, while flexibility is the capability to handle alternate (desirable) operating conditions.

A further distinction between resiliency and flexibility is suggested by Colberg et al. (1989). Flexibility deals with planned, desirable changes that often have a discrete set of values, resilience deal with unplanned, undesirable changes that naturally are continuous values. Thus a flexibility is a 'multiple period' type of problem. A resilience problem should be a problem with a continuous range of operating conditions in the neighborhood of nominal operating points.

In order to make Alternative 6 of HDA plant more economically appealing, the minimum number of auxillary utilities is identified using the proposed design

scheme adapted from Wongsri's RHEN (for resilient heat exchanger network) design method.

Wongsri (1990) developed the heuristic and procedures for resilient heat exchanger network synthesis. The heuristics are used to develop basic and derived match patterns which were classified according to their (1) resiliency (2) chances that they are in solution and (3) the matching rules like the pinch method, and the thermodynamics law etc. Furthermore the same author developed for synthesize heat exchanger network called "The Disturbance Propagation Method". This method will find a resiliency network structure directly from the resiliency requirement and also feature minimum number of units and maximum energy recovery.

3.7.2 Design Conditions

There are several design conditions for resilient HEN synthesis. Usually, these are specified at extreme operating conditions. The following conditions (Wongsri, 1990) are:

1. *Nominal Operating Condition.* This is an operating condition that is obtained from a steady state heat and mass balance of a process. In a good design, a network must be operated at this condition most of the time. In general, a fluctuation in operating condition is plus and minus from this point.
2. *Maximum Heat Load Condition.* This is a condition where all process stream are at their maximum heat loads. For example inlet temperatures of hot streams are the highest and of cold streams are the lowest. This is also known as the largest maximum energy recovery condition.
3. *Maximum Cooling Condition.* This is a condition where hot process streams are at their maximum heat loads whereas cold process streams are at their minimum heat loads. For example inlet temperatures of hot and cold streams are the highest.
4. *Minimum Heating Condition.* This is a condition where hot process streams are at their minimum heat loads whereas cold process streams are

at their maximum heat loads. For example inlet temperatures of hot and cold streams are the lowest.

5. *Minimum Heat Load Condition.* This is a condition where all process streams are at their minimum heat loads. For example inlet temperatures of hot streams are the lowest and of cold streams are the highest. This is also known as the lowest maximum energy recovery condition.

The worst case condition of this work is the condition that minimum heat supplies by hot process stream and maximum heat demand by cold process stream. This viewpoint is shown in Figure. 3.4.




Figure 3.4: A viewpoint of worst case condition

3.7.3 Match Patterns

HEN synthesis is usually considered as a combinatorial matching problem. For a HEN in which a design property is regarded as a network property, or a structure property, we need to look beyond the match level to a higher level where such a property exists, e.g. to a match structure or match pattern. Match patterns are the descriptions of the match configuration of two, possibly more process streams and their properties that are thermally connected with heat exchangers. Not only the match

description, e.g. heat duty of an exchanger and inlet and outlet temperatures is required but also the position of a match, e.g. upstream or downstream, the magnitude of the residual heat load and the heat capacity flowrates between a pair of matched streams. So, we regard the resilient HEN synthesis problem as a match pattern combinatorial problem where more higher - level design qualities are required.

By using the 'tick off rule' there are four match patterns for a pair of hot and cold streams according to the match position and the length of streams. The four patterns are considered to the basic match pattern classes. The members of these classes are the patterns where other configurations and properties are specified. The four match pattern classes are simply called A, B, C and D and are shown in Figure 3.5 to 3.8 respectively.

1. Class A Match Pattern: The heat load of a cold stream is greater than the heat load of a hot stream in a pattern, i.e. the hot stream is totally serviced. The match is positioned at the cold end of the cold stream. The residual heat load is on the hot portion of the cold stream. (See Figure 3.5)

A match of this class is a first type match at cold end position and the heat load of the cold stream is greater than that of the hot stream. This is a upstream match. For a heating subproblem, a Class A match is favored, because it leaves a cold process stream at the pinch heuristics.

2. Class B Match Pattern: The heat load of a hot stream is greater than the heat load of a cold stream in a pattern, i.e. the cold stream is totally serviced. The match is positioned at the hot end of the hot stream. The residual heat load is on the cold portion of the hot stream. (See Figure 3.6)

A match of this class is a second type match; a hot end match and the heat load of the hot stream are greater than that of the cold stream. This is an upstream match. For a cooling subproblem, a Class B match is favored, because it leaves a hot process stream at the cold end also follows the pinch heuristics.

3. *Class C Match Pattern:* The heat load of a hot stream is greater than the heat load of a cold stream in a pattern, i.e. the cold stream is totally serviced. The match is positioned at the cold end of the hot stream. The residual heat load is on the hot portion of the hot stream. (See Figure 3.7)

A match of this class is a first type match; a cold end match and the heat load of the hot stream are greater than that of the cold stream. This is a downstream match.

4. *Class D Match Pattern:* The heat load of a cold stream is greater than the heat load of a hot stream in a pattern, i.e. the hot stream is totally serviced. The match is positioned at the hot end of the cold stream. The residual heat load is on the cold portion of the cold stream. (See Figure 3.8)

A match of this class is a second type match; a hot end match and the heat load of the cold stream is greater than that of the hot stream. This is a downstream match.

When the residual heat load in a match pattern is matched to a utility stream, it is closed or completed pattern. Otherwise, it is an open or incomplete pattern. It can be seen that if the heat load of the residual stream is less than the minimum heating or cooling requirement then the chances that the match pattern will be matched to a utility stream is high.




Figure 3.5: Class A Match Pattern




Figure 3.6: Class B Match Pattern




Figure 3.7: Class C Match Pattern




Figure 3.8: Class D Match Pattern

3.8 Design of Heat Pathways for Dynamic MER

For the plantwide energy management, the heat pathways through the network are designed so that the dynamic MER can always be achieved. In this work, the heat pathways are designed based on the match patterns design and disturbance propagation technique (Wongsri, 1990)




Figure 3.9 Heat pathways in the simplified HEN to achieve the highest possible dynamic MER, where: (a) path 1 is used to shift the positive disturbance load of the cold stream C_1 to the cooler, (b) path 2 is used to shift the negative disturbance load of the cold stream C_1 to the heater, (c) path 3 is used to shift the positive disturbance load of the hot stream H_1 to the heater, and (d) path 4 is used to shift the negative disturbance load of the hot stream H_1 to the cooler.

A simplified HEN as shown in Figure 3.9 is used to explain how an appropriate heat pathway should be activated to carry associated load to the utility unit. For instance, when the inlet temperature of a disturbed cold stream decreases, path 1 (Figure 3.9a) should be activated by controlling the cold outlet temperature of FEHE. This will have the effect of shifting the positive disturbance load to the cooler. Thus, the positive disturbance load of a cold stream will result in decrease of the cooler duty. Consider the case when the inlet temperature of a disturbed cold stream increases, path 2 (Figure 3.9b) should be activated by controlling the hot outlet temperature of FEHE to shift its negative disturbance load to heater. Thus, the negative disturbance load of a cold stream will result in decrease of the heater duty.

On the other hand, when the inlet temperature of a disturbed hot stream increases, path 3 (Figure 3.9c) should be activated by controlling the hot outlet temperature of FEHE to shift its positive disturbance load to heater. As a result, the heater duty will be decreased. Consider the case when the inlet temperature of a disturbed hot stream decreases, path 4 (Figure 3.9d) should be activated by controlling

the cold outlet temperature of FEHE to shift its negative disturbance load to cooler. As a result, the cooler duty will be decreased.

3.9 Design and Control of Heat Pathways for Heat Exchanger Networks

The LSS can be used to select an appropriate heat pathway to carry associated load to a utility unit. In this chapter, we figure out the heuristics of selection and manipulation of heat pathways for some typical HEN examples that widely used in the petroleum and chemical industries (e.g. HEN alternatives of HDA process given by Terril and Douglas, 1987). We also show where the LSS should be placed on a heat exchanger unit so that it can be used to direct the disturbance load to a specified utility unit.

For all of the examples of HENs, we assume that:

- The utility exchangers can handle all variations of heat load.
 - The path for disturbance loads is co-current with all of the process streams.
 - Any heat exchanger will have enough heat transfer area to accommodate increases in heat loads of disturbed process stream.
- Bypass lines are provided to all heat exchangers as a standard feature to adjust heat load